

Installation 1. Install the arm adapter on the LED shoebox with four fixing screws. 2. Install accessories and tighten screw according to exploded pictures. (as shown) Adjusting angle screw Cover plate Silicone Silicone Arm licone Cover plate 1/2 blocking 1. Install the slipfitter adapter on the LED shoebox and fix it with four screws.2. Install accessories and tighten screws according to exploded pictures. (as shown) Adjusting angle screw Slip Fitter 1/2 blocking Silicone Cover plate 1. Install the slipfitter-2 adapter on the LED shoebox and fix it with four screws.2. Install accessories and tighten screws according to exploded pictures. (as shown) Adjusting angle screw Slip Fitter-2 Silicone 1/2 blocking Cover plate 1. Install the waterproof connector and tighten it with a wrench. Install the U bracket to the LED shoebox and tighten the screws.3. Install another U bracket on the 1st U bracket , tighten the rotary screw and the positioning angle screw. (as shown)