

STEP 1

Ensure the surface is sound, clean and free from grease, oil, rust, scale, dirt, or any other soiling that might affect adhesion. Prior to application ensure you have the following equipment ready.

- Gas Torch
- Tape Measure
- PPE
- Chalk
- Broom
- ProTack Primer
- ThermaMark R117



STEP 2

Lay out and pre-mark using **Meon Road Crayons** to show where product will be installed then place marking to one side.

Using a gas torch, pre-heat surface where product is to be laid to remove any moisture and provide a warm surface to enable bonding.



STEP 3

Use **Meon ProTack** aerosol primer for improved adhesion and longevity. Wait 5 minutes for primer to dry.

Place the marking in position and use gas torch to heat. Move the torch side-to-side over the marking, holding upright and no closer than 150mm. Avoid holding the torch in one place, as this will cause the thermoplastic to scorch.



STEP 4

You will notice the product beginning to shrink/melt into the surface profile. The edges will also 'bevel off' as it melts. Apply heat until the whole area is fully bonded to the surface.

The product can be trafficked as soon as it has cooled to ambient temperature.



SPECTRUM



Please read and understand the technical information of this product prior to application.

If you require a copy, contact us on 023 9220 0606 or email mail@meonuk.com

MEON UK

RAILSIDE, NORTHARBOUR SPUR,
PORTSMOUTH, PO6 3TU

TEL: +44 (0)808 118 1922
WEB: MEONUK.COM

MEON IRELAND

48 BRIDGE ROAD, BURREN,
WARRENPOINT, BT34 3QT

TEL: +353 (0)1 840 7647
WEB: MEON.IE