

WC-DCRDS WIRE CHUCK INSTALLATION

Having already removed your existing chuck you are left with your DCRDS with the bare shaft. If the shaft is a 5mm diameter shaft you will want to do the following.

1. Put the 1st sleeve over the shaft and push it to the back of the shaft against the motor housing
2. The 2nd sleeve should be placed inside Wire Chuck.
3. Align the hole on the slip clutch with the hole through the shaft and slide it into place.
4. Put the allen head bolt through the brass, once completely through the slip clutch unit you can put the locking nut back on the bolt.

INCLUDED:

- WIRE CHUCK
- 2 SLEEVES

