

MHX[®] GAFF INSTRUCTIONS

WORLD CLASS ROD BLANKS

INSTRUCTIONS FOR WINN WRAPPED GAFFS



STEP 1: MARK DISTANCE

Use a china marker to mark off the area where you will install each handle component and use this as a blueprint for the build.



STEP 2: ADD TAPE

Take double-sided tape and double wrap the gaff blank by spiraling up and back down with the tape in a candy cane pattern.



STEP 3: ADD HANDLE

Soak double-sided tape with mineral spirits, as well as the inside of the EVA handle. Slide EVA onto the gaff blank from the butt end up.



STEP 4: SAND BUTT END

After cutting away excess tape from the exposed butt end of the gaff blank, sand the butt end of the blank before adding ProPaste epoxy.



STEP 5: APPLY BUTT

With the butt end scuffed and ready, apply ProPaste epoxy to butt end of the gaff blank and install the fighting butt by twisting it into place.



STEP 6: WRAP WINN TAPE

Cut the Winn tape for a flat edge (as directed in the Winn tape box) remove backing from tape and wrap to desired length.



STEP 7: FINISHING TAPE

Use provided Winn finishing tape to secure the ends of your Winn tape wraps



STEP 8: ANOTHER HANDLE

To add EVA fore grip, soak the inside of the EVA with mineral spirits and apply ProPaste on the gaff blank. Slide the grip down into place.



STEP 9: GLUE HOOK

After sanding the male section of the gaff blank, apply ProPaste epoxy to the stepped blank tip and follow up with the gaff hook.

VIDEO INSTRUCTIONS AVAILABLE AT [MUDHOLE.COM/MHX-GAFF-KITS](https://www.mudhole.com/mhx-gaff-kits)