





GATE SHOWN IS OPTIONAL, STANDARD MODEL IS WITH CHAIN

KeeHatch® *Mightylight* Model KHML 4848, this model is attached to the counter flashing KeeHatch in Aluminum

| <u>#Q</u> | Kee Lite® | <u>#Q</u> | <u>Pipe</u> | <u>Size</u> | <u>#Q</u> | <u>ltem</u> | <u>Size</u> |
|-----------|-----------|-----------|-------------|-------------|-----------|---------------------|-------------|
| 2 | L10-7 | 4 | Stubs | 8" | 1 | 3/16" Chain | 39" |
| 2 | L15-7 | 2 | Posts | 30" | 1 | "S" hook | |
| 4 | 121-7 | 4 | Posts | 42" | 1 | Quick link | |
| 8 | 133C | 4 | Rails | 48" | 16 | Fastclip | |
| 4 | L135-77 | | | | 16 | 3/8" X 1 1/4" bolts | |
| 4 | L161-7 | | | | 1 | Product Label | |
| 2 | 178-7 | | | | 1 | Warranty Card | |
| | | | | | | · | |

Tools Needed Using RailingReady® Roof Hatches & Mounting to Counter Flashing

- wrench to tighten bolts to Fastclip
- torque wrench
- 5/16" hex key to tighten Kee Klamp® set screws
- bolt cutter to remove excess chain
- drill and bit will be required if hatch is not RailingReady

INSTALLATION

- STEP 1 hold L161-7 against counter flashing, slide fast clip over L161 and behind counter flashing
- **STEP 2** bolt L161-7 to Fastclip, repeat for 4 corners
- **STEP 3** insert posts into L161-7's, torque set screws to 29 foot pounds
- STEP 4 slide 178-7's onto 30" posts
- **STEP 5** insert other rails as per diagram, torque set screws to 29 foot pounds,
 - slide 178-7's to top of 30" posts and torque to 29 foot pounds
- STEP 6 install chain, "S" hook, quick link onto 178-7's. Install 133C plugs

