

Tools Needed Using RailingReady® Roof Hatches & Mounting to Counter Flashing

- wrench to tighten bolts to Fastclip
- torque wrench
- 5/16" hex key to tighten Kee Klamp® set screws
- bolt cutter to remove excess chain
- drill and bit will be required if hatch is not RailingReady

INSTALLATION

- **STEP 1** hold L161-7 against counter flashing, slide fast clip over L161 and behind counter flashing
- **STEP 2** bolt L161-7 to Fastclip, repeat for 4 corners
- STEP 3 insert pre-assembled posts into L161-7's, torque set screws to 29 foot pounds
- **STEP 4** slide 178-7 onto top rails
- **STEP 5** insert top and mid rails into L135-77's, flush to front posts, torque set screws to 29 foot pounds, slide 178-7's to front post and torque to 29 foot pounds
- STEP 6 install chain, "S" hook, quick link & 133C plugs

