

**Flat6 Bi-LED Headlight Upgrade Kit**

**Porsche 964 89-94**

**LED Options Wiring Instructions**

Read all instructions before beginning the install to become familiar with the install procedure.

Be sure power is turned off to all lights during the install procedure.

**1) Remove the Turn Signal and Parking Light from the front bumper.**

a) Remove the screw in order to access the turn signal housing.



b) To remove the second screw partially retaining the Parking light housing.



c) Then remove the cover of the plastic part beside the Parking Light.



d) Now remove the plastic part in order to access the Parking Light housing.



e) You can now access the connector of the Parking Light housing in order to plug the wires from the LED Angel Eye.



## 2) Pass and connect the wires from the headlight bucket to the Parking Light connector.

a) You can pass LED Angel Eye 3 wires or the LED Parking Lights 2 wires from the headlight housing to the Parking Light connector in the front bumper using one of the holes illustrated here.



b) Pass the wires to the connector.



c) Use the T-Tap connectors to connect the wires from the LED Angel Eye or Parking Light using the color on this illustration:

- Green wire on the connector with the Orange wire from the LED Angel Eye.
- Red wire on the connector with the White wire from the LED Angel Eye.
- Brown wire on the connector with the Black wire from the LED Angel Eyes (the LED Angel Eyes ground could also be Tapped to the Brown wire from the Headlight connector in the bucket).



### 3) Reassemble the Parking Lights and Turn Signals in the bumper.

a) Use the same process to put all parts back in place.



### 4) Installation complete.