

## Flat6 Bi-LED Headlight Upgrade Kit Porsche 993 95-98 LED Option Installation Guide



*LED Surround*



*LED Angel Eye*



*4LED*

Read all instructions before beginning the install to become familiar with the install procedure.

Be sure power is turned off to all lights during the install procedure.

Unpack the headlights and all components from the protective packaging. Check that all parts are undamaged in the shipping container before you begin the install.

### 1) Uninstall the existing headlights.

a) Please refer to the 993 Bi-LED Headlight Installation Guide for this process.

### 2) Connect the LED to the Parking Light.

a) Remove the Turn Signal housing from the front bumper.



b) Pass the LED wires from the headlight bucket to the Turn Signal bucket in the front bumper.



c) Connect the LED wires using T-Tap terminals to the wires from the Turn Signal/Parking Light socket.  
If you have LED Angel Eyes and/or LED Surrounds: (using the wire extension)

- LED black wire to the brown wire (ground).
- LED Red wire to the Parking Light wire.
- LED Yellow wire to the Turn Signal light wire.

If you have 4LED:

- LED black wire to the brown wire (ground).
- LED red wire to the Parking light wire.



d) Reinstall the Turn Signal housing in the front bumper.



### 3) Installation complete.