

Flat6 Bi-LED Headlight Upgrade Kit Porsche 993 95-98 Lens Installation Guide



Read all instructions before beginning the install to become familiar with the install procedure.
Be sure power is turned off to all lights during the install procedure.

1) Uninstall the headlights.

a) Please refer to the 993 Bi-LED Headlight Installation Guide for this process.

2) Uninstall the trim rim and the lens.

a) Remove the six screws around the trim rim cover.



b) To remove the trim rim, grab it by the sides and pull it out slowly.



c) Then separate the lens and the trim rim.



3) Installation of the lens inside the trim rim.

a) Push the lens inside the trim rim until it is well seated in the neoprene seal around the trim rim.



4) Installation of the trim rim/lens around the headlight housing.

a) Start by the top to insert the trim rim/lens around the headlight housing/reflector.



b) Align the trim rim screw hole with the top hole and put back the screw in place without tightening the screw too much to avoid cracking the plastic parts.



c) Align the trim rim bottom hole with housing then put in place the screw.

d) Then you can proceed to put back the side screws.



5) Installation complete.