

Technical Note

Porsche 933 Flat6 illumination Headlights Wiring to Replace Litronic Headlights

Flat6 headlights are not plug & play for the Litronic headlight connector. However, you can adapt the wiring to the following configuration to make it work:

- Pin 1: Low Beam, connected to the fuse box low beam fuse.
- Pin 2: not connected
- Pin 3: High Beam connected to the fuse box high beam fuse.
- Pin 4: Connected to the ground.

The pins 3 and 4 are supposed to be wired the same way on the standard halogen headlight as it is in the Litronic so no modification should be necessary.

The Flat6 illumination headlight is only using the pins 1, 3 and 4 as shown on the attached picture..

If you have Litronic headlights you need to ensure that pin 1 will bring regular 12v current from the fuse box as it is on the halogen headlight.

