

ABARTH 500/595/695 TMC INTERIOR ARMREST INSTRUCTION MANUAL

Step 1: Remove the rubber floor on the front cupholder as seen in photo (1) with a flat screwdriver.

Step 2: Position the armrest over the cupholders at the end of the central tunnel.

Step 3: Insert the supplied screw into the hole of the storage floor & secure the screw with a hand screwdriver.

Step 4: Insert the supplied rubber or felt panel on the storage floor.

