



DESCRIPTION	QTY.
FOOTPACK LONG BASE	2
ULTRA HIGH BRACKET	2
M8 X 16mm COACHBOLT	8
M8 X 25 ALLEN SOCKET BUTTON HEAD BOLT	4
M6 NYLOC NUT	4
M8 NYLOC NUT	12
M6 X 25 ALLEN SOCKET CAP HEAD SCREW	4
M6 FLAT WASHER	8
M8 FLAT WASHER	16
RUBBER WASHER	4
5mm ALLEN KEY	1

INSTALLATION INSTRUCTIONS (150mm ELEVATION):

1. SLOT ALL OF THE M8 X 16mm COACHBOLTS INTO THE LIGHTBAR BASE
2. ASSEMBLE THE FOOTPACK LONG BASES WITH THE ULTRA HIGH BRACKETS USING M8 X 25 BOLTS, WASHERS & NYLOC NUTS
3. ASSEMBLE THE BRACKETS WITH THE LIGHTBAR BASE USING M8 NYLOC NUTS & WASHERS, EVENLY SPACED OR AS REQUIRED
4. PLACE THE ASSEMBLY ON VEHICLE ROOF/INSTALLATION POINT & MARK OUT DRILLING POSTIONS
5. DRILL 4 X 6.5mm HOLES TO SUIT M6 CAP HEAD SCREWS
6. ASSEMBLE THE LIGHTBAR TO THE VEHICLE/INSTALLATION POINT USING M6 CAP HEADS, RUBBER SPACERS, M6 NYLOC NUTS & WASHERS. (IF REQUIRED, APPLY WATERPROOFING SEALING AGENT AT THIS STAGE)
7. ENSURE ALL NUTS & BOLTS ARE TIGHT

NOTE: TO INSTALL AT 115mm ELEVATION, RE-ORIENT BRACKET AS SHOWN IN FIG. B

<small>THIS DRAWING IS CONFIDENTIAL AND IS THE EXCLUSIVE PROPERTY OF REDTRONIC LTD. NO UNAUTHORISED USE, COPY OR DISCLOSURE OF THE DRAWING IS TO BE MADE AND IT IS TO BE RETURNED WHENEVER REQUIRED.</small>	PROJECTION 	SCALE 1:2.5 DRAWN WO	UNLESS STATED DIMENSIONS MM TOL. LINEAR ±0.3 TOL. DIAGONAL ±0.5 TOL. ANGULAR ±0.5	MATERIAL SEE PARTS LIST	 <small>MANUFACTURERS OF EMERGENCY EQUIPMENT</small> TITLE ULTRA HIGH PROFILE FIXING KIT SHEET. 1 OF 1 DWG NO EM108UHP REV A
	IF IN DOUBT ASK A3	DATE 09/09/2020 WEIGHT 1.77 kg	FINISH N/A		
	<small>NO UNAUTHORISED USE, COPY OR DISCLOSURE OF THE DRAWING IS TO BE MADE AND IT IS TO BE RETURNED WHENEVER REQUIRED.</small>				
	<small>THIS DRAWING IS CONFIDENTIAL AND IS THE EXCLUSIVE PROPERTY OF REDTRONIC LTD. NO UNAUTHORISED USE, COPY OR DISCLOSURE OF THE DRAWING IS TO BE MADE AND IT IS TO BE RETURNED WHENEVER REQUIRED.</small>				