HOW TO INSTALL THE ATN THOR RISER BLOCK

- (1) Using a 1/8" hex bit, remove the two screws from the bottom of the QD Picatinny Mount. Note: the screws might have been installed using LOCTITE®, so if they feel as though extra force is needed to remove them, stop immediately, as heat may be necessary to soften up the LOCTITE®. Details on how to do so. is listed below.
- (2) After removal, clean the threaded holes in the ATN Thor and the surfaces of the Mount with a Q-Tip dipped in acetone or a similar solvent. Follow the manufacturer's instructions for its use.
- (3) Position the Riser Block on the top of the Mount. Before putting them together, spread a thin layer of the enclosed LOCKITE® on the mating surfaces. Then install the two longer screws in the bottom of the Mount and through the Riser Block. Place a drop of LOCTITE® on the exposed threaded ends of the screws.
- (4) Before assembly, spread a thin layer of LOCTITE® on the top of the Riser Block and the mating underside surface of the ATN Thor. Then put them together and finger-tighten the two screws. Note: At this point, the heads of the screws should be close to bottoming out in the recesses of the Mount. If they stick up more than 1/16", the threaded hole might not have been properly cleaned.
- (5) Tighten the two screws alternately, to <u>35 INCH POUNDS</u> using the 1/8" hex bit. Note: do not over tighten as the hole threads might strip.
- (6) Allow the LOCTITE® to dry for 24 hours before mounting the ATN Thor to a firearm.

NOTE: To soften the LOCTITE®, locate a disposable a 1/8" allen wrench. Place the end of the wrench in the hex hole of the screw and apply heat to the allen shaft only, using a controlled flame. This allows for heat to be transferred through the shaft to the screw, which should make for easier screw removal. WARNING... DO NOT APPLY HEAT DIRECTLY TO THE QD MOUNT OR ATN THOR AS PERMANENT DAMAGE MIGHT OCCUR.

NOTE: Installing our ATN Thor Riser Block is very easy. If however, you are having difficulty or are uncomfortable installing it, please contact us for assistance.

P.O. BOX 263
PEGRAM, TN 37143
info@repackbox.com