

WOCA Direct

877-962-2645 info@wocadirect.com

WOCA Exterior Oil Samples by Hand

1. Dampen a clean cloth with water and wipe the sample evenly to open the wood grain and allow it to thoroughly dry.
2. Pour a small amount of **WOCA Exterior Oil** onto the wood. Spread and polish the oil with a cloth or a piece of **red pad**. Leave the oil to soak on the sample for 5 minutes.
3. Wipe off the surface oil with a cotton cloth. When finished, there should be no oil on top of the wood. Leave the sample to dry for 5 – 6 hours.
4. Repeat the oil application with the **white pad** as in #2 & #3 above. You will use less oil than during the first application.

Warning! Rags, pads or waste soaked with WOCA oil may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.