



WOCA WOODCARE

☎ 877-962-2645 ✉ info@wocawoodcare.com

WOCA Precolor Instructions

Pre-Color is a water-based stain used for the priming of unfinished or newly sanded interior woodwork i.e. floors, stairs, furniture and paneling. Pre-Color colors and enhances the wood grain prior to finishing with a WOCA Penetrating Oil. Pre-Color may be used on all types of wood.

1. Apply the undiluted Pre-Color in an even layer lengthwise onto the floor with a brush or a paint roller
2. On vertical woodwork, apply from top to bottom.
3. When the wood is dry, remove any visible pigments from surface with a green pad under a floor buffer and then vacuum the floor clean.
4. Finish the floor with WOCA Master Color Oil or WOCA Diamond Oil Active.

Packaging: 2.5 liter

Coverage: 250 sf per container