



WOCA WOODCARE

☎ 877-962-2645 ✉ info@wocawoodcare.com

WOCA Oil Samples by Hand

1. Dampen a clean cloth with water and wipe the sample evenly to open the wood grain and allow it to thoroughly dry.
2. Pour a small amount of **WOCA Master Color Oil, Diamond Oil, or Diamond Oil Active** onto the sample. Spread the oil with a cloth or a piece of **red 3M pad**. The surface should be visibly wet. Leave the oil to soak on the sample for 15 minutes.
3. Wet buff with the red 3m pad to force oil into the wood, buff/polish it well. Wipe off the surface oil with a cotton cloth. When finished, there should be no oil on top of the sample and you should have a silky look. Leave the sample to dry for 5 – 6 hours.
4. Repeat the oil application as in #2 & #3 above. You will use less oil than during the first application.

Note: The use of red and white 3M pads will simulate a buffer application which forces more oil into the wood and smooths the wood grain.

Warning! Rags, pads or waste soaked with WOCA oil may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.