



## WOCA WOODCARE

 877-962-2645  [info@wocawoodcare.com](mailto:info@wocawoodcare.com)

### WOCA OUTDOOR WOOD PRIMER - APPLICATION INSTRUCTIONS

**Outdoor Wood Primer is a water based product for priming outdoor wood like e.g. facades, windows, fences etc. it improves adhesion and durability. The product is used primarily for pine, Accoya, larch, spruce, oak and old pressure treated wood (except red cedar). Pressure-treated wood and hardwood may be treated directly with the WOCA outdoor products.**

#### **Work Instructions:**

1. Application only in dry weather and at temperature over 15°C (59°F). Avoid heat and direct sunlight. The moisture content of the wood should not exceed 17% when applying Outdoor Wood Primer.
2. The wood must be clean and completely dry. New woodwork should be primed as soon as possible. With old woodwork, previous applications must be removed. Clean with Exterior Cleaner and leave the wood to dry for at least 24 hours. The wood must be completely dry before continuing.
3. Apply with brush or paint roller. Begin with the end grain of the wood – from below and upwards. Apply in full length to avoid overlaps.
4. Leave the Primer to dry for approx. 24 hours before application of the WOCA outdoor products. After priming, it is necessary to protect with one of the WOCA outdoor products.
5. Clean tools with warm water.