

NOTE:

- 1. BEFORE APPLICATION OF UNITED COATINGS™PMMA FLASHING MEMBRANE, FLEXSEAL™CAULK GRADE SEALANT SHOULD BE USED TO FILL VOIDS WHERE ROOFING MEMBRANES TERMINATE AT PENETRATIONS.
- 2. REFER TO GAF PREPARATION GUIDELINES FOR PROPER SURFACE TREATMENT OF ALL MATERIALS PRIOR TO APPLICATION OF UNITED COATINGS "PMMA FLASHING SYSTEM
- 3. A NAILER AND TREATED WOOD CANT MAY BE REQUIRED FOR COMPLIANCE WITH SPECIFIC BUILDING CODES OR APPROVALS.
- 4. UNITED COATINGS PMMA CANNOT BE APPLIED IN THE ABOVE CONFIGURATION OVER MEMBRANES OR OTHER MATERIALS CONTAINING UNCURED, SOLVENT-BASED MATERIALS, CONTACT GAF FOR INFORMATION.
- 5. REFER TO GAF FLEECE CUTTING RECOMMENDATIONS FOR CONFIGURATIONS, CUTTING, FOLDING, AND LAPPING TECHNIQUES.
- 6. REQUIREMENTS AND RECOMMENDATIONS DETAILED IN CURRENT GAF SPECIFICATIONS AND THE UNITED COATINGS ™PMMA FLASHING SYSTEM INSTALLER'S GUIDE SHALL APPLY IN ADDITION TO THE ABOVI
- 7. DO NOT USE OVER COLD-APPLIED OR APP SYSTEMS.

