



Neptune Carbon Fiber Scoop Handle Instructions

Neptune Carbon Fiber Scoop Handles are available in 5 different diameters sizes and will fit an assortment of scoop styles from different manufactures. Be sure that you have the proper fitting handle to your scoop as an over tight or lose fit may cause premature wear to the handle.

You will want to make sure that the scoop socket is free from burrs, weld burn through and excess paint. A “snug” fit is acceptable but you need to make sure that you will be able to get the handle all the way to the bottom of the scoop socket.

Different methods of fasteners can be used to fasten the handle depending on the style of scoop. A 1/4 Inch stainless steel bolt with washers and lock nut is included. Many styles use a bolt through the side of the scoop socket and handle. In this case you may need to install the handle then drill a ¼ inch hole and use the provided nut and bolt. A few styles do not require a through bolt as the scoop socket has an outside clamping design.

After you have installed the handle it is a good idea to apply the included Neptune decal on the front of your handle to aid in locating the front of your scoop bucket when it is under water.

Note – For 2 Piece travel handles be sure to take apart and rise with clean water . It is also a good idea to apply lube after each use.

Anderson Detector Shafts

550 Murdock Ave.
Fort Erie, Ontario
L2A 1S4
Canada