



## Neptune Carbon Fiber Scoop Handle Instructions

#0610 - 1 1/4" (1.25) Carbon Fiber Handle

#0611 - 1 3/8"(1.375) Carbon Fiber Handle

#0611T - 1 3/8" (1.375) Carbon Fiber Travel Handle

The Anderson Neptune Scoop Handle comes in two diameter sizes and will fit an assortment of scoops from different manufactures. Be sure that you have a proper fitting scoop as an over tight or lose fit may cause premature wear to the handle.

You will want to make sure that the scoop socket is free from any burrs or weld burn through. A "snug" fit is acceptable but you need to make sure that you will be able to get the handle all the way to the bottom of the scoop socket.

Different styles of scoops will have different methods of fasteners. Included are two stainless 1/4x2" bolts with lock nuts. Most assembly will use one bolt through the side of the scoop socket and handle. In this case you will need to install the handle then drill a 1/4" through the handle and attached and tighten the nut. Some styles may use two bolts. A few styles do not require a through bolt as the scoop socket has an outside clamping design.

After you have installed the handle it is a good idea to apply the included Neptune decal on the front of your handle to aid in locating the front of your scoop bucket when it is under water.

Note- for 2 piece handles (travel) be sure to take apart and rise with clean water and apply lube after each use.

### **Anderson Detector Shafts**

550 Murdock Ave

Fort Erie, ON

L2A 1S4

Canada