



STRIVO LUME Installation Guide

Kit Contents

Plugged LED Driver

LED Tape reel with 2MTR power lead

The LED Driver is to be used only with the LED Tape supplied in the kit.

Aluminium Profile length including diffuser, end caps and fixing clips*

Installation (for LED Tape kit use)

Ensure the surface is clean and dust free by using the 3M surface prep wipe. Allow 2 minutes for the surface to dry.

If you need to reduce the length of the tape, partially peel back the red strip on the reverse of the tape.

Cut the tape at the indicated cut points using a sharp pair of scissors.

Fix the LED Tape to the surface applying pressure along the length to ensure a firm bond.

The micro connector plug on the LED Tape power lead should be placed into the black distribution block on the LED Driver.

Installation (for use with Aluminium profile)

The Aluminium profile, diffuser and LED Tape can be cut to the desired length if required.

Remove the opal diffuser from the aluminium profile. The profile end cap where the cable exits need to be cut to position the cable to exit towards the rear of the end cap.

Insert the LED Tape and opal diffuser - ensure all filings and swarf are removed before applying the LED Tape.

Fix the profile into place using the clips provided.

*Components included in Aluminium profile kit

