

FORD FIESTA ST CATCH CAN STAGE 2

TOOLS REQUIRED

M4, M5 allen wrench
Flat screw driver
Box cutter
Heat gun
Work gloves

MATERIALS REQUIRED

<p>1</p> <p>Remove the engine cover.</p>	<p>2</p> <p>Remove the right most bolt holding the intake manifold. Remove the sound symposer bushing.</p>	<p>3</p> <p>Remove the engine cover.</p>	<p>4</p> <p>Install the Catch Can bracket.</p>
			
<p>5</p> <p>Install the Catch Can. Adjust the position and tighten the clamp.</p>	<p>6</p> <p>Disconnect the vent hose.</p>	<p>7</p> <p>Oil the supplied fittings.</p>	<p>8</p> <p>Cut the vent hose. Heat the ends with the heat gun. Install the fittings and secure them with hose clamps. WEAR HEAVY DUTY WORK GLOVES TO PREVENT BURNS.</p>
			
<p>9</p> <p>Install the factory vent hose with the fittings installed.</p>	<p>10</p> <p>Press vent lines onto the Catch Can's fittings. Secure the hoses with the hose clamps. Longer hose to "OUT", shorter hose to "IN".</p>	<p>11</p> <p>Route the vent lines on the top of the intake manifold. Connect the vent lines to the factory vent lines and secure them with the hose clamps. Use zip ties to dress up the vent lines.</p>	<p>12</p> <p>Install the engine cover.</p>
			