



GARAGE DOOR SPARES

TM

# G3 Cable Fitting Instructions

## Fitting Instructions

### Garador current canopy cables (G3)

#### Copyright notice

Please note that, unless stated otherwise, the copyright to all material on this website is the property of Weather Stop Ltd. We rigorously protect our rights under UK Copyright Law and will actively pursue any infringements.

- 1 Tighten the two grub screws in the left hand side spring casing.
- 2 Thread the end of the cable into the slot of the roller bracket assembly
- 3 Undo the two grub screws in the cable drum, slide the cable drum towards the centre of the door.  
The cable can now be inserted into the fixing slot.  
Rotate the drum so that the cable winds onto the rear of the drum.  
Ensure the cable runs down the inside of the track.  
When the cable is taut, slide the drum to the outside and tighten both grub screws.  
Repeat for opposite side.
- 4 Undo the two grub screws that were tightened in step 1.

**Please note: All work is undertaken at your own risk.**