

Built-in and beyond

The methods with which worktops can be built-in have become increasingly more varied and customized. Foster was the first sink manufacturer to have researched and used the new recessing methods and has thus acquired a great deal of experience. It now offers the most comprehensive range available on the market, with flush-mount, flat-edge and undermount installation.




Standard

Traditional built-in with the vertical, 8-mm edge.



Q4

The casing has a square edge that stands on the work surface by just 4 mm. Great solution to match the sink with the ceramic glass hobs (Induction).



Flat-edge

An original edge, with an inclined, 3 mm high profile, matching an extreme elegance with the easiness of installation.



Flush-mount

The product is sunk in 1,5 mm deep recess thus being perfectly flush with the worktop. As alternative, it can be installed on the worktop as well.



Undermount

A classy and contemporary idea, to be installed under the worktop; available in various types of sinks, with soft or square design.



Built-in

The most stylish and assertively professional solution is to weld the sink to the stainless steel worktop, producing one sleek, seamless block.

Flush-mount & Flat-edge: a clarification to be done

Many manufacturers indicate as Flat-edge a Flush-mount edge mounted on the worktop.



For Foster Flat-edge means a real alternative built-in solution with an elegant 3 mm sloping edge.



In any case, Foster's Flush-mount models can be mounted on the worktop (as in the detail in the picture), thus offering a further built-in solution.

