



This plastic integrated stop plate comes as a free gift with your Google package:

It sets the no-parallax-point (NPP) of your new panorama head quickly and precisely. Setup guide: Push the stop plate to the base of lens ring and snap it in place. The hole needs to be at the bottom. Install the attached safety pin from top of R10/R20 and remove any other safety pins already installed. Attach lens ring to your R10/R20, the safety pin goes in the hole of the stop plate. The safety pin needs to be installed in a position that gives these values on the side ruler of your lens ring base (the longest mark on your R10/R20 top clamp shows the value).

No-parallax settings for the new V2 lens rings on R10:

- Canon F4 8-15 = 2.1
- Sigma F3.5 8mm for Canon = 0.45
- Sigma F3.5 8mm for Nikon = 1.4

No-parallax settings for the new V2 lens rings on R20:

- Canon F4 8-15 = 2.5
- Sigma F3.5 8mm for Canon = 0.9
- Sigma F3.5 8mm for Nikon = 1.85