



**ADVENTURE  
FURTHER®**

**DITCH LIGHT INSTALLATION GUIDE  
2021+ FORD BRONCO  
#97156 - #97161**

## INSTALLATION INSTRUCTIONS

*WARNING: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.*



### Ditch Light Installation Guide

1. Remove the two factory Torx bolts using a T30 and a T25 tool.
2. Install the lights onto the ditch brackets, but do not fully tighten.
3. Place the light and bracket assembly into position by loosely re-installing the outer-most Torx bolt.
4. Use a plastic panel removal tool to pry up the plastic panel along the windshield to open a gap and route the wiring pigtail/connector into the engine bay.
5. Re-insert the remaining factory Torx bolt and line the bracket into position and fully tighten both bolts.
6. Aim and fully tighten the lights.
7. Wire according to the instructions included with the wiring kit (or to factory-equipped Upfitter Switches, if applicable).



### PRODUCT REGISTRATION

Thank you for becoming part of the KC family and purchasing one of our premium KC products! With over 50 years of history in the auxiliary lighting market, you have become a part of our ever growing family, and we encourage you to register your product online at [HTTP://REGISTER.KCHILITES.COM](http://register.kchilites.com) to ensure you get all the benefits of owning a KC HILITES product.