

## ADF Subaru 3/4" Carrier bearing spacer install



1. Remove heat shield, M10 socket
2. Remove the (2) M14 bolt the carrier from the body, while supporting it with your hand to keep it from falling.
3. Install new spacer between the body and the carrier and install the new provided hardware. Torque hardware to 22 Ft/Lbs
4. Re install heat shield. Note: You may need to bend it a little to fit back on there as we have changed the location of the carrier.