



Mezza Oak Towel Rail

.wireworks

Thank you for purchasing this Oak Bathroom Towel rail.

Assembly HINT:

Do not fully tighten the fixings before the complete item is assembled. For best results the fixings should be tightened once all components are correctly in position.

When complete place the towel rail on a FLAT surface and tighten each part so that the towel rail is rigid, level and stable.

Fitting Instructions:

You will need a **philips screw driver** to assemble this product.

1 Screw the **x4 lug screws** into the metal holes on the towel rail uprights. Make sure these are FULLY tightened .

2 Push the **x4 lug holders** into the side blocks making sure that the smaller side holes line up with the holes on the lug holders.

3 Take the shorter towel upright and fix the x 2 side blocks. Note that the side block has two holes at one end and a single hole at the other. The end with the single hole fixes to the shorter towel upright. The **lug holder** can NOW be loosely tightened.

4 Take the taller towel upright and insert the **x2 dowel pegs** into the wood holes above the **lug screws**. Push the side blocks into position with the taller upright and loosely tighten the **lug holder**.

BE CAREFUL TO SUPPORT THE TOWEL RAILS AT THIS STAGE AND DO NOT PUT UNDUE STRESS ON THE FIXINGS.

5 Using the **x 4 screws** fix the foot blocks to the bottom of the towel rail uprights. Tighten securely.

6 Place the towel rail upright on a flat surface. Now tighten the **lug holders** fully. Check the stability of the completed item. If the legs are not level loosen all four **lug holder screws** and re-tighten.

Warnings:

Fix together in accordance with manufacturers instructions. Do not leave wet towels or garments in prolonged contact with wood surfaces as this may damage the lacquer.

Cleaning:

Wipe using a soft damp cloth or chamois leather. Use a mild soap solution if necessary. Do not use washing powders or any other substance containing abrasives or bleaching compounds since these substances will damage the lacquer finish.

Complies with BS 7449: 1991.

Finish: PU Lacquer. Water resistant.

Model ref: Mezza Towel Rail 2012 Oak Batch X

Supplied by Wireworks 43a Mercers Road London N19 4PP.
www.wireworks.co.uk