

Classic Trim Parts LLC

1083 Delaware Avenue

Buffalo NY 14209

716-931-9551

classictrimpartsllc@gmail.com

Dome Light Assembly Instructions

To remove and replace the dome light assembly, grasp the base of the spring-loaded rear-view mirror and pull it off. Detach any HomeLink wires connected to the mirror. Set the mirror aside. There are three screws attached to a metal plate and two screws behind the two dome lights that hold the console in place. Pry the two lights out with a small screwdriver to access the screws behind these bulbs. Detach any wiring connections and remove the assembly.

Removal and replacement of the electronic “guts” of the assembly is fairly straightforward. There are six visible points or dots where the black plastic electronic plate is attached to the molded outer assembly. Five of the six are easily visible while the sixth is just behind the cylindrical buzzer on the upper right-hand side. Use a Dremel to detach or cut away those six spots. Make sure these holes are opened wide and free of any plastic or glue residue. Remove the plastic insert including the switches and replace in new molded outer assembly. Make sure the insert seats properly including the switches. Use some epoxy to secure the attachment spots. Once dry, replace the unit in the car.

Classic Trim Parts

classictrimparts.com

Classic Trim Parts LLC

1083 Delaware Avenue

Buffalo NY 14209

716-931-9551

classictrimpartsllc@gmail.com

