

Classic Trim Parts LLC

1083 Delaware Avenue

Buffalo NY 14209

716-931-9551

classictrimpartsllc@gmail.com

Vanity Mirror Installation Instructions

- 1) Look at the new mirror and you will see two small indentations on the lower frame on the opposite side at the hinged upper frame.

- 2) Take a thin screwdriver and pop the old mirror off the sun visor by snapping it off where those two small areas on the old vanity mirror meet the backing plate on the sun visor body. Remove the old unit.

- 3) Inspect the backing plate for cracks and damage. Replace if necessary, using a Phillips screwdriver. There are six small Phillips screws holding it in place. A new backing plate in your selected color is included with your order free of charge.

- 4) With the mirror shut, slide the upper frame (hinged) tabs into place and then snap on the three bottom tabs on the lower frame into the backing plate. **If you push in the bottom tabs first, you will likely break off the top tabs, when snapping it into the backing plate.**