



COWL HOLE

32"

POSITION FLUSH TO TOP OF FRAME

5 TO 7° LAYBACK

AXLE

THACKER © 24

#2024

1932 FORD CROSS MEMBER INSTALLATION

TO POSITION THE CROSS-MEMBER, MAKE YOUR MEASUREMENT FROM THE COWL HOLE ON THE FRAME, FORWARD 32". THIS IS THE POSITION FROM CENTER OF THE AXLE'S POSITION IN THE FRAME. DEGREE THE CROSS MEMBER BACK 5 TO 7° TACK, THEN CHECK ANGLE AND THEN WHEEL BASE. (100") THEN MAKE FINAL WELD!

Pete & Jake's Hot Rod Parts • 401 Legend Lane • Peculiar, MO 64078 • 1-800-334-7240