

PADHOLDR PHONE SERIES

PHONE SETUP AND TABLET INSTALLATION GUIDE

SETUP

A. Loosen the two tensioners (a) and carefully attempt to slide your phone in to the holder. Determine if you will need to change the installed spacers so your phone, with or without its case, fits firmly into the holder.

B. To change the installed spacers, use the included allen-wrench to remove the four (b) bolts on the face of the holder. Exchange the spacers with the proper size, re-install the bolts and attempt to fit your phone once again.

C. Once the phone fits firmly and fully seated in the holder, adjust the two tensioners so they sit against the sides of your phone, then tighten them down.

Note: Keep tensioners installed unless you are using 0.75" or larger spacers. If so, swap the installed tensioners out with the longer tensioners and screws included in the package.

