

# Hyundai i30 Rear Reading Light LED Board install

Tools required: Flat head screwdriver, soldering iron

## Step 1:

-Using a flathead screwdriver, gently lever off the clear cover from the light unit at the marked locations.



## Step 2:

-The frame can be removed from the light unit as per Figure 4 & 5 to reveal the LED board.



## Step 3:

-Desolder the three red marked pins shown in Figure 6. **Make note of how the board sits in the frame.**





**Step 4:**

-Insert the MaxLume board and re-solder at the three points. **NOTE: Circuit board must sit at an angle like the OEM board.**

-Take the lens from the OEM board and place in the holes provided on the MaxLume board over the LED chips.



**Step 5:**

-Insert the frame back into the light unit over the board and replace clean cover

