

SFR TJ/LJ Track bar bracket install guide

Please read all instructions before beginning.

Safety Warning

Any modification to your steering, brakes, or suspension will alter how your vehicle drives. Care must be taken to avoid loss of control or rollover of modified vehicles. SFR Products are sold for Off-Road vehicles. The driver of the vehicle is responsible for its safe operation and use

1. Park vehicle on flat level surface, engage parking brake, and put transmission in park or in gear
2. Remove old track bar from factory mount
3. Using a 5/8" drill bit, carefully enlarge the tapered hole in the factory track bar mount.
4. Slide SFR mount into place and attach using supplied 5/8" bolt. Torque 180ft.lbs.
5. Using holes in bracket as a guide, drill 1/2" through holes in frame, and torque bolts to 80ft.lbs.
6. (optional) This bracket may also be welded in place.
7. Center the vehicle body over the axle and install new track bar.

SFR TJ/LJ Track bar bracket install guide

Please read all instructions before beginning.

Safety Warning

Any modification to your steering, brakes, or suspension will alter how your vehicle drives. Care must be taken to avoid loss of control or rollover of modified vehicles. SFR Products are sold for Off-Road vehicles. The driver of the vehicle is responsible for its safe operation and use

1. Park vehicle on flat level surface, engage parking brake, and put transmission in park or in gear
2. Remove old track bar from factory mount
3. Using a 5/8" drill bit, carefully enlarge the tapered hole in the factory track bar mount.
4. Slide SFR mount into place and attach using supplied 5/8" bolt. Torque 180ft.lbs.
5. Using holes in bracket as a guide, drill 1/2" through holes in frame, and torque bolts to 80ft.lbs.
6. (optional) This bracket may also be welded in place.
7. Center the vehicle body over the axle and install new track bar.