



DCCSTANDS.COM SALES@DCCSTANDS.COM 847-266-1220

Lane/8000 Keypad Protective Spill Cover Installation Instructions

You have made a great choice to protect your device from germs, spills and grime while extending the life of your Terminal/PIN Pad!

1. Clean the keypad area so that it is free of dust and grime.
2. Place the cover over the keypad, being careful to align the keypad properly over the keys.
3. Remove the FRONT mylar only, and adhere just the FRONT tape.

*If the tape comes off with the white strip, simply reapply the tape to the cover and carefully separate the tape from the white mylar.

4. Remove the LEFT, RIGHT, and BACK mylar and adhere.

Final Step: Smooth down all edges of the cover.

Tips for Care and Use

- This cover is durable, but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.