



DCCSTANDS.COM SALES@DCCSTANDS.COM 847-266-1220

Magtek 30056028 PINpad Full Device Spill Cover Installation Instructions

CONGRATULATIONS!

You have made a great choice to protect your device from germs, spills and grime while extending the life of your terminal.

INSTRUCTIONS:

1. DO NOT REMOVE THE WHITE MYLAR STRIPS YET.
2. Place the cover on the device, making sure the keypad portion of the cover is lined up with the keys properly.
3. Keeping the cover in place with one hand, remove the front white Mylar strip with the other hand. Secure the front tape down.

This is the tape just below the red, yellow, and green keys.

*If the tape comes off with the white strip, simply reapply the tape to the cover and carefully separate the tape from the white Mylar.
4. Remove the white strip from the TOP and adhere. Making sure the screen is aligned properly.
5. Secure the RIGHT side next by removing the white strip, next adhere the LEFT side. Adhere the strips by stretching to make sure there are no bubbles.
6. Check and smooth down any bubbles. You can safely lift up the edge to stretch and reapply the cover.

Tips for Care and Use

- This cover is durable but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.