

DCCSTANDS.COM <u>SALES@DCCSTANDS.COM</u> 847-266-1220

Verifone P200/P400/V200/V400/V400M Full Device Spill Cover Installation Instructions

CONGRATULATIONS!

You have made a great choice to protect your device from germs, spills and grime while extending the life of your terminal.

INSTRUCTIONS:

- 1. Clean the device so that it is free of dust and grime. Let dry.
- 2. Take off just the white mylar tape strip off of the middle tape.
- 3. Flip up the edges of the bottom keyboard section. Align the cover over the keypad. Take off the three bottom white strips.
- 4. Flip down the three bottom sides and adhere the tape.
- 5. Flip up the three edges of the top screen section. Take off all three white strips.
- 6. Moving from the bottom of the screen to the top, adhere the glue strips to the device. Adhere the top strip last by flipping it down.
- 7. Finish by smoothing down the bubbles, and adjusting the fit.

Tips for Care and Use:

- This cover is durable but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.