

Dynavin MOST Adapter Install for Fiber Optic Integration in Porsches D8-PS and D8-PC

The MOST adapter is also referred to as the MOST box. Please note that when replacing the factory head unit in a fiber optic-equipped car, the head unit's fader function will no longer function since the fiber optic connection to the car's amplifier is only 2-channel. All the speakers in the car will still work and the fader in the amp will default to the centered position. Please see the wiring layout on the next page for reference.

1. With the D8-PS units there are two main wire harnesses included. Determine which harness fits your car's plug (AN-7054A or AN-7054-B). There's one small black plug on the main wire harness that plugs into the MOST box. There are 2 multi-pin connections on the MOST box. Plug in the one that matches the plug on the harness; the other plug will not be used. Make sure the plug clicks in all the way.
2. Unclip the fiber optic cables from the factory radio plug and connect them to the MOST box.
3. On the Dynavin harness there are 2 RCA plugs coming from the MOST interface box plug. Connect those to the **FRONT RCA outputs** on the back of the Dynavin.

Note: We recommend connecting your phone via Bluetooth and making a phone call. If you cannot hear the person talking that you called, the RCA outputs are not plugged into the FRONT RCAs. Check your connections.

4. It is good practice in car audio to remove any obsolete devices from the fiber optic system like a CD changer, navigation drive, or telematics unit. Simply unplugging them will break the fiber optic signal chain which may result in no audio from the speakers. So, it is recommended that a "MOST fiber optic bypass loop (female)" be plugged into the fiber optic system in the place of the obsolete device. The manufacturer has started to include one with the Dynavin. They are also available on Amazon, eBay, etc. or at most local car audio shops.

See the wiring layout on the next page

If you need further assistance, please email support@dynavinnorthamerica.com

Dynavin MOST Adapter Install for Fiber Optic Integration in Porsches D8-PS and D8-PC

