

# Wheel Set Installation Instructions

---

for the Barista Express Impress

CREMA  
coffee products

**IMPORTANT:**

***Disconnect your machine from its power source and allow the machine to cool completely before moving forward with your installation.***

**STEP 1**

Remove the drip tray, accessory tray and water tank from your machine.



## STEP 2

Gently rest your machine on its side, providing access to the bottom of the machine.

To protect the machine, and to *catch residual water* from the water tank's inlet, lay a towel on your workstation before tipping the machine.

*TIP: Instead of laying the machine on its side, you can also access the bottom of the machine by (carefully) hanging one side of the machine over the edge of a countertop and working from the floor, one side of the machine at a time.*

CREMA  
coffee products



### STEP 3

Using a Philips screwdriver, remove the existing rubber feet from the back corners of the machine.

Replace with the matching wheel assembly and secure with the factory screws.

*CAUTION: Do not over tighten screws.*



## STEP 4

Remove the factory front foot by removing the two screws holding it in place.

Find the matching Crema foot and separate the rubber insert from the foot's base by pulling the two pieces apart.

Attach the base of the Crema foot using the factory screws.

*CAUTION: Do not over tighten screws.*

Align the plugs on the rubber insert with the holes in the base and press firmly.

Repeat for the second foot assembly.

CREMA  
coffee products



## STEP 5

*Replace your drip tray, accessory tray, water tank and...*

***...Get Rollin'!***

