

# Wheel Set Installation Instructions

---

for the Barista Pro

CREMA  
coffee products

**IMPORTANT:**

***Disconnect your machine from its power source and allow the machine to cool completely before moving forward with your installation.***

**STEP 1**

Remove the drip tray, accessory tray and water tank from your machine.



## STEP 2

Gently rest your machine on its side, providing access to the bottom of the machine.

To protect the machine, and to *catch residual water* from the water tank's inlet, lay a towel on your workstation before tipping the machine.

*TIP: Instead of laying the machine on its side, you can also access the bottom of the machine by (carefully) hanging one side of the machine over the edge of a countertop and working from the floor, one side of the machine at a time.*

CREMA  
coffee products



## STEP 3

Using a Philips screwdriver, remove the existing rubber feet from the front corners of the machine.

Note that the two screws will be different lengths and in the next step, should be replaced into the same hole from which they were removed.



## STEP 4

Separate the rubber insert from the foot's base by pulling the two pieces apart.

Match the foot's base to the correct side of the machine by aligning the notched holes.

Attach the base with the screws from STEP 3, ensuring proper placement of the short / long screw.

*CAUTION: Do not over tighten screws.*

Align the plugs on the rubber foot with the holes in the base and press firmly.

Repeat for the second foot assembly.

CREMA  
coffee products



## STEP 5

Remove the rear factory feet by removing the two screws holding them in place, taking note of the screw sizes and the holes from which they were removed.

Match the correct wheel assembly to each corner by orienting the wheel in the direction shown.

Attach the assembly with the previously removed screws.

*CAUTION: Do not over tighten screws.*



## STEP 6

*Replace your drip tray, accessory tray, water tank and...*

***...Get Rollin'!***

