



PHONE: (989) 435-7080

3195 LYLE ROAD • BEAVERTON, MI 48612
www.howeracing.com

FAX TOLL FREE: (888) 484-3946

WINDSHIELD PROTECTOR FILM INSTALLATION INSTRUCTIONS

Needed for Installation: Water, baby shampoo, water sprayer, lint free towel, window squeegee, hard squeegee, clean working space.

1. Cut film to size.



Step 1



Step 2

2. Clean the windshield using a mixture of about 100 parts water to 1 part baby shampoo. Apply the mixture using a spray bottle. Spray and wipe off first with a lint free towel. Spray and wipe off second with a squeegee.

Note:

If you see foam in your mixture, you have used too much baby shampoo and the film will not want to stick. If you use too little, the film will stick too easily and create bubbles under the film.

Having the surface completely clean of all impurities is crucial to a smooth seal.

3. Separate the film from the plastic.

- a. Some spray will help start the separation.
- b. Use two people to separate, one holding the film, one taking off the plastic while spraying lightly with the liquid mixture.



Step 3



Step 4

4. Spray the windshield with another thin coat of the liquid mixture.



5. Put the film on the windshield using two people, one holding each side.

a. Make sure to stick down the corners and each side well so that when smoothing out, it doesn't slide. The film must be placed correctly the first time. It will not stick properly if peeled off and placed again.



6. Start from the middle with a hard squeegee to work out all the bubbles and a lot of the moisture. This part takes patience. Make sure you don't push too vigorously and move the film or cause creases.

Note:

The whole process could take 10-45 minutes. When approaching an hour, you may be better off to peel it off, throw it away, and start over.

There will be stubborn spots that won't lay down easily. Be patient. Do not go too fast or you may crease it and then not be able to smooth it out.

If there is a piece of dust or fiberglass between the film and windshield, air will get in and a bubble will form, making it difficult to work completely out. Therefore, it is very important to keep both surfaces clean the entire process.

If you see something on the edge between the layers or there is a small crease preventing a seal, you may try to carefully scrap it out with a razor knife or small putty knife.

7. When finished, watch it for a while and let it set. Spots may pop back up and need worked out a couple times. Do not wash it until it's been given time to set.

8. Squeegee once more to clean off remaining moisture and any streaks.

