INSTALLATION INSTRUCTIONS



150 Series Mounting Instructions







FITMENT: MWL-155 AND MWL-156S

MOUNTING PROCEDURE:

For ease of mounting your quick release bar, please follow these easy steps!

1. Align front clip in bushing flanges and push forward. You may need to pull the sides of the backrest slightly outward to fit snugly.

2. Rotate backrest bar back until rear latches touch rear bushings.

3. With thumbs on the base of bar, use index fingers to lift latch pads slightly, and let bar rotate rearward to seat latches in rear bushings.

4. Now push on the pad backward toward the end of the fender to allow latches to rotate into locked position.

5. With thumbs, push down on latch pads to check full engagement of latches

You can also go to our website, search for "MWL-156S", click on the product and watch the YouTube video for instructions on how to mount your quickrelease rack/bar.

Great Rides Start With Motherwell

Motherwell Products USA, Inc 7074 Portal Way #140 Ferndale, WA 98248 Toll Free (877) 703-7118 www.motherwellproducts.com

1.