

INSTALLATION INSTRUCTIONS

Doc#M665-K24



MWL-166-1

FITMENT:

Fits on MWL-155 and MWL-156S Backrests

MAX CAPACITY: 10 lbs

MATERIAL: 5/8" Tubular Steel

TECHNICAL SPECS: 6x8" carrying surface

WELCOME: These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product as it contains valuable information necessary to the end user.

CAUTION: Start screw carefully to avoid cross threading.

USE AND CARE:

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners. We recommend the use of non-abrasive automobile wax to polish our products. This will best maintain the appearance of the product and increase longevity.

WARNING: Never carry more than 10 lbs. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose nor come in contact with moving parts, i.e., wheels, brakes, etc....

TOOLS REQUIRED:

5/32" or 4 mm Allen Wrench
Kit #24

PARTS INCLUDED: MWL Part #

Rack MWL-166-1
4 SS MG Flat Washers FAS-54

MOUNTING PROCEDURE:

- 1) Remove backrest from the bike if installed.
- 2) Remove 4 bolts on the inside of the Sissybar side plates on Rack mounting block.
- 3) Slide luggage rack from inside bottom backrest to align with existing bolt holes.
- 4) Reinsert the 4 bolts & the provided washers and tighten until just snug, check rack is square, and adjust as needed, then tighten bolts fully.
- 5) Reinstall bar on bike.

Great Rides Start With Motherwell

Motherwell Products USA, Inc
7074 Portal Way #140
Ferndale, WA 98248
Toll Free (877) 703-7118
www.motherwellproducts.com