

# INSTALLATION INSTRUCTIONS

DOC#M430-K2



## MWL-430/430B

### FITMENT:

Touring models 97-Up

**MAX CAPACITY:** 10 lbs

**MATERIAL:** 3/8" Solid steel centers, 1/2" tubing

### TECHNICAL SPECS:

Pillion Seat Replacement

Will not fit with a Corbin Seat

**WELCOME:** These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

**ATTENTION INSTALLER (if other than owner):** Please forward this instruction sheet to the purchaser of this product as it contains valuable information necessary to the end user.

**CAUTION:** Start screw carefully to avoid cross threading.

### USE AND CARE:

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals, cleaners. We recommend the use of non-abrasive automobile wax to polish our chrome products. This will best maintain the appearance of the product and increase longevity.

**WARNING:** Never carry more than 10 lbs. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose nor come in contact with moving parts, i.e., wheels, brakes, etc....

### TOOLS REQUIRED:

#2 Phillips Screw Driver  
Kit #2

### PARTS INCLUDED:

Luggage Rack  
1 Phillips 3/4" Pan Head Screw  
1 1/4 Bond Seal S/S  
1 Foam Tab

### MWL Part #:

FAS-009, FAS-057, FOAM-AFT

### MOUNTING PROCEDURE:

- 1) Remove Pillion seat.
- 2) Install foam on back of the rack.
- 3) Slide rack into slots on front mounting knobs.
- 4) Install the stock screw in to rear pick up point on the rack. (DO NOT TIGHTEN)
- 5) For the front mount, place the nylon washer on the rack with the stainless steel on top.
- 6) From there insert the supplied Phillips screw loosely.
- 7) Proceed to tighten both screws down.

Great Rides Start With Motherwell

Motherwell Products USA, Inc  
7074 Portal Way #140  
Ferndale, WA 98248  
Toll Free (877) 703-7118  
[www.motherwellproducts.com](http://www.motherwellproducts.com)