

INSTALLATION INSTRUCTIONS

Doc#M667-K23



MWL-667MB/667GB



FITMENT:

Fits on 691S and 691T (Indian Chieftain, Springfield, Roadmaster, & Challenger)

MAX CAPACITY: 10 lbs

MATERIAL: 3/4" Tubular Steel, 12-gauge CR Steel

TECHNICAL SPECS:

Fits MWL-691s & MWL-691T (MB/GB/CH)

WELCOME: These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product as it contains valuable information necessary to the end user.

CAUTION: Start screw carefully to avoid cross threading.

USE AND CARE:

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners. We recommend the use of non-abrasive automobile wax to polish our products. This will best maintain the appearance of the product and increase longevity.

WARNING:

Never carry more than 10 lbs. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e., wheels, brakes, etc...

TOOLS REQUIRED:

7/16" Wrench or 11 pt. Wrench Kit 23 (included)

PARTS INCLUDED:

Luggage Rack
Hex Cap Screw
4 SS MG Flat Washers

MWL Part #:

MWL-667, FAS-002, FAS-054

MOUNTING PROCEDURE:

1. Remove backrest from the bike if installed.
2. Remove 4 existing bolts on the inside of the Sissybar side plates on Rack mounting block.
3. Slide luggage rack from inside bottom backrest to align with existing bolt holes.
4. Insert the 4 bolts provided and tighten until just snug, check rack is square, and adjust as needed, then tighten bolts fully.
5. Reinstall bar on bike.

Great Rides Start With Motherwell

Motherwell Products USA, Inc
7074 Portal Way #140
Ferndale, WA 98248
Toll Free (877) 703-7118
www.motherwellproducts.com