

Basket Assembly

Installing a wire basket to your beach cruiser will take approximately 5-10 minutes. Following the below instructions (using the pictures as a guide), you can properly and safely install your wire basket

All you will need for installation of the basket is a screwdriver and a wrench.



Parts included: Wire Basket, Basket Stay, Stem Bracket, Clamp, screws (4 pcs), washers (4 pcs), nuts (2 pcs)

First, install the basket stay to the basket using the screws / washers and clamp provided. To make sure it is snug, but still allow some give to allow movement of the bracket during installation.



Next, loosen the handle bar stem, head sets (lock nut and spacer) from the bike, loop the basket bracket onto the headset area (to replace the spacer you took out earlier). Screw the headset (locknut) back, install the stem back to the bike.



Next, install the bracket onto the basket using the screws / washers and nuts provided.



Now remove axle nut that hold the front wheel, place the axle mounting hole on axle, replace axle nut and tighten. Be sure the front wheel is aligned properly in fork.



Completely tighten all screws & nuts, wheel axle nuts, and your basket is installed and ready for use.

Warning: Do Not overload basket. Do Not mount basket stay to the inside of the bicycle front fork. Do Not assemble a quick-release front hub through basket stay hole.