



8V A3/S3 Carbon Spoiler Install Guide

Factory Spoiler Removal

The factory spoiler is held on by adhesive tape. The easiest way to remove it is to start in one corner with gentle heat. Use a piece of dental floss and slide it under the edge. Move the floss back and forth in a sawing motion to cut the adhesive underneath the spoiler. If this proves difficult, use a bit more heat to soften the adhesive underneath. Once the spoiler is removed, clean up the deck lid by rolling the remaining adhesive with your finger.

PURE Spoiler Install

If you are using our install kit, begin by wiping the underside of the spoiler with the adhesive promoting wipe. Using the supplied 3M adhesive tape, cut into ½" to 1" sections. Try to refrain from touching the adhesive side, as dirt will affect adhesion. Place the small sections along the spoiler where it will affix to the trunk, paying particular attention to the far edges (as this is where the spoiler will lift if not fully mounted). Once you have laid down sufficient tape, remove the red backing from it. Before placing the spoiler, wipe the trunk edge down with the adhesion promoting wipe. Only wipe in the areas where the spoiler will affix to. Guide the spoiler into place onto the trunk, paying careful attention to the ends. We prefer to line up the ends first and affix them, then move to the middle. When you are satisfied with the location, apply pressure to allow it to mount. If you have any questions, please feel free to email sales@emmanueledesign.com



