

Due to the thickness of the RS3 grille, the pre-sense radar will need to be moved up for better visibility. The process to do this is shown below.

**Drill new mounting hole approximately 0.4" below existing holes. You will want to ensure that bolt head has sufficient clearance around the plastic adjusters shown.**



**Next, mount the bracket using the new holes. Mount the black metal bracket on the back of the cast metal bracket, with the bolt heads facing the rear of the vehicle. This is reversed from how it was mounted originally, as it allows the bracket to sit higher.**





