



Edge Pull Installation Instructions

Before Starting:

- For new installations, **pre-drilling holes is required**. **Important Note: *If you do not pre-drill holes, you risk the screws snapping inside the cabinet. Inspire Hardware is not responsible for any installation issues if these installation instructions are not followed.***
- Tightening of screws should be done manually with a screwdriver to avoid over-tightening or stripping the screws or hardware.

Required Tools:

1. Drill
2. 3/16" drill bit
3. Screwdriver
4. Pencil or pen

Optional:

5. Painter's tape

Installation Steps:

1. Place the edge pull on the cabinet where you would like to install them.
2. Once you're happy with placement, from the back of the cabinet door or drawer, use a pencil to mark the screw holes. *If you don't want to mark up your cabinet, you can use a piece of painter's tape in the area where the screw holes will go, and make the marks on the painter's tape.*
3. Take your drill and 3/16" drill bit, and set the bit to the depth of the screws provided.
4. Use the drill to pre-drill holes into the back of the cabinet, taking care not to drill through the front.
5. Once the pilot holes are drilled in the correct spots, place the pull in the correct spot with the holes aligned.
6. Use a screwdriver to tighten the screws into the cabinet. *If using a drill for the step, there are risks to stripping the screws or snapping them in the cabinet, therefore it is recommended to use a screwdriver.*
7. Stand back and enjoy your new hardware!

For Questions, please:

Email info@inspirehardware.com

Call (206) 717-4030

Or use our online chat feature