



## WALL MOUNT

### **Installation Instructions:**

- 1.** Measure and mark the four wall mount holds at the appropriate height and space on your wall.  
Recommended mount height is 50" - 60" above the floor.
- 2.** Drill four pilot holes where marked.
- 3.** Drive a drywall anchor into each pilot hole.
- 4.** Place the wall mount against the wall and line up the holes of the wall mount with the holes on the wall. Drive a screw through each hole. Be careful to not over-tighten.